

ARCADEPRO®

Proteus 9270



Home[®]
LEISURE
DIRECT
- Serious Fun -

User Manual

Setting Up

Proteus Console Inputs



Powering Up

Note: The USB ports seen on the side of the console are not used.

To switch the unit on, plug the power cable into a wall socket, then the connecting lead into the **Power Plug** on the side of the machine. The machine can then be switched on using the right hand switch (labeled DC12V), which will also switch on the machine's lighting.

Both screens display the same image.

Controlling the Volume

Volume can be turned up or down with a small dial on the side of the machine.

Connecting to External Monitors or Screens

If you wish, you can connect the console to an external monitor or television using either the side HDMI or VGA ports (cables not included).

Machine Controls

Each player shares the same basic controls.


Player 1 is Blue.

Player 2 is Red.



Basic Menu Controls

Pandora Games 3D is an easy to navigate menu system that will give you easy access to every game on the system. The system allows you to tailor the games list to your liking, and begin/end games at your leisure. Below gives a basic outline as to what each control button will do.

	Up – Scroll up		
 Joystick	Down – Scroll down	 A Make Selection	 Pause Pause/Exit Game/Save /Load
	Left – Page back		
	Right – Page forward	 Player 1 Start and Insert Coin	 Player 2 Start and Insert Coin

Your ArcadePro machine will boot up to the main games list screen when switched on.




To switch to the games list, scroll to the top of the list where the currently seen list will be highlighted. You can then move left or right using the **Player 1 joystick** to switch between the lists.

Use the **Player 1 joystick** to navigate through the lists, then select your game with the **Player 1 A button**.

Search Function



Pandora Games 3D includes a very useful search function that can help you to find your favourite games in seconds, without having to scroll through the entire games list.



To find this option, highlight the games lists at the top, then navigate right to select the search function. In this menu, you can use the **Player 1 joystick** and **Player 1 A button** to type what you want to search for with the on-screen keyboard. You can delete letters with the **Player 1 B button**.

As you enter in letters, the list on the left will begin to fill with games that match your search term. You can use the **Player 1 joystick** and **Player 1 A button** to select and play any of the search results.

When you exit the game, you will return to your original search results, where you can play another result, search for another game or navigate back to the main games lists.

In-Game Controls

When a game is loaded, a 1 player game can be started with the **Player 1 Start button**. A 2 player game can be started with the **Player 2 Start Button**. Pressing either of these buttons also acts as inserting a virtual coin, should the game you're playing require them.

A game can be paused or quit at any time by pressing either **Pause Button**, where you will be given the option to resume your current game, or quit back to the Pandora Games 3D menu.

Every time a game is loaded from the menu, it is loaded 'from fresh', meaning that high scores are not saved between games, unless saved manually by the player using the saving and loading system.

Saving and Loading a Game

Note: Every time a game is loaded, it is loaded 'from fresh', meaning that high scores are not saved between games unless saved manually by the player using the saving and loading system.

The system allows you to save your progress at any point, and then return to that point at a later time. This is achieved by saving a "State".


About "States"

On this ArcadePro system, a "State" can be described as a specific point or moment when in the game. When you load a state, you will return in the game to the exact moment where you saved it.

States can be saved or loaded at any point of the game.

On this system, there can only be one state per game. Each new state you save will overwrite the last.

How to use



To access the save and load system, pause the game you're currently playing using the **Pause** button, then save the state by pressing the **Player 1 C** button. You can resume the game by hitting the **Player 1 A** button.

To load the last state you saved, pause the game using the **Pause** button, then press the **Player 1 D** button to load the most recent save state. Resume the game by hitting the **Player 1 A** button.

Pandora Games 3D Options

Pandora Games 3D features an options screen that allows you to customise your unit.

Accessing The Options Menu

To access the options on your unit, press the small Settings Switch on the side of the machine.

The options list contains a comprehensive list of settings that can customise your ArcadePro machine. Below outlines the options that you can modify.

Pandora Games 3D System Settings Menu



You can return to the games list by pressing the **Player 1 D** button.

We do not recommend modifying any options not covered by the following list. Doing so can result in reduced functionality of your system for general users.

- **Key Settings** – Use this to test input functionality on all joysticks and buttons, or to re-map the controls.
- **Auto exit** – Set the amount of time a game spends idle before returning to the main menu.
- **Image Optimisation** – Select one of a few preset visual filters (including adding scan lines)
- **Language** – Use to change the system’s default display language.
- **Enter Game Settings** – Customise the games list. Use to hide or display what appears in the games list. Also alter certain games’ difficulty.
- **Burst Setting** – Enable auto-fire input by holding a button.
- **Factory Data Reset** – Restore all the system’s factory default settings.

Customising Your Games List

The games list can be changed using the “Enter Game Settings” option in the Pandora Games 3D Settings Menu.



This list will give you complete control over the games on your system from difficulty to creating a custom favourites list. Below outlines what each option allows. Refer to the on-screen instructions for how to navigate these options.

We do not recommend modifying any options not covered by the following list. Doing so can result in reduced functionality of your system for general users.

- **Edit Difficulty and Life** – Alter certain aspects of a game’s difficulty, including number of lives and other settings (varies depending on game).
- **Edit Favourite List** – Bookmark your favourite games.
- **Edit Game List** – Hide or show selected games on your games list.
- **Delete Game** – Select a game to permanently delete from the system.
- **Delete All Games** – Permanently delete every game from your system.

Edit Game List



Game Will Be
Displayed



Game Will Be
Hidden

Hiding certain games on the 2D games list can make it easier to find your favourite games on the system by displaying only the games you wish to see.

If a game in the list is prefixed with its number, then it will be displayed in the 2D games list upon exiting.

If a game is prefixed with a **red X**, then it will be hidden in the 2D Games List upon exiting.

Troubleshooting:

Wrong Language on Startup

There's a slim chance that upon arrival, your machine will not be in English. This is an occasional leftover from checks during production and is easily rectified.

1. Access the Options Menu (See page 7)
2. Scroll down to Language (7th option down)
3. Press A until the language changes to English
4. Exit as normal

No Sound

If there is no sound on your ArcadePro system, check to see if the amplifier on the system is turned up using the small dial on the side of the machine.

If problem persists after these checks, contact us.

Have Fun!



Any Other Questions?
Tel - 0800 622 6464
sales@homeleisuredirect.com

